FABRIC BUILDING INSTRUCTIONS

MODEL: SH-RO253015

L9.2 x W7.6 x H 4.6



PICTURE MAY NOT REFLECT THE EXACT MODEL

TO OUR NEW AND VALUED CUSTOMER

Thank you for purchasing your new Instant Shelter. We know you will have as much pleasure owning your new shelter as we had in making it for you. Our shelters have been designed for rapid assembly and minimal maintenance. We have rigorous quality control at every step of the shelters manufacturing process to insure you the best unit money can buy. Our parts are triple checked prior to packaging to insure you will have everything you need before you start. In the unlikely event that a part is damaged or missing, you should immediately contact your place of purchase for a speedy replacement.

About Safety

HEAD PROTECTION IS RECOMMENDED!

Working with or under heavy parts included with this shelter can cause serious head injury.

WEAR GLOVES

You will be working with metal parts which may have SHARP edges

CHECK WITH YOUR LOCAL AUTHORITIES

Underground POWER CABLES or GAS LINES may result in injury while securing the shelter. It may also result in having to move the building. A cursory check with the local building authorities will help alleviate these concerns.

CLIMBING EQUIPMENT

It is highly recommended that scaffolding, ladders and mechanical lifting equipment conform to all local building codes when erecting the shelter. Safety straps and harnesses should be used at all times. The metal structure of the shelter has not been designed for human weight. Erecting shelter during wind or rain is unsafe and could result in serious injury.

CHECK LOCAL WEATHER CONDITIONS

Check your local weather forecast prior to planning your building day. Wind, snow and/or rain may cause unsafe conditions that could lead to serious injury.

STORING HAZARDOUS MATERIALS

Check all local building codes prior to storing any hazardous material. Shelter may require additional ventilation to meet local codes.

SEVERE WEATHER CONDITIONS

Working in and around the portable shelter during severe weather is not recommended. Serious injury could result. In the event that extraordinarily severe wind, snow or other severe conditions are predicted and if time permits, it is recommended that the shelter cover be removed.

PREVENT ENTRAPMENT

Check Shelter for co workers before locking up. Always provide for escape in case of emergency.

SHELTER RELOCATION

Should the shelter require relocation or disassembly for any reason, it is strongly recommended that the structure and its cover are thoroughly inspected prior to rebuilding.

PERIODIC SHELTER INSPECTION

As with all structures, periodic inspection of the cover and all structural-components is highly recommended. Tightening the cover and the structure will prolong the life of your investment.

PLEASE BE **Safety** CONSCIOUS!

Common Sense is the knack of seeing things as they are, and doing things as they ought to be done.

THANK YOU FOR CHOOSING OUR SHELTER

UNPACKING & IDENTIFYING PARTS

Prior to assembling your New Portable Shelter, unpack all crates and complete an inventory of all parts according to the following list and diagrams


Parts#	Descriptions	Diagram	Dimensions (in mm)	Q'TY	BOX
1	Top roof arched rafter(left)	12	Φ60x2000	6	1
2	Roof arched rafter	ele ele	Φ60x2000	14	1
3	Roof arched rafter(lower end)	2/20	Φ60x2000	4	1
4	Side curved rafter		Φ60x1155	12	1
5	Side vertical rafter(leg)	(o o (o)	Φ60x1800	12	2
6	Door frame vertical tube(lower)	O •)	Φ60x1800	4	2
7	Door frame vertical tube(upper)	Cinco in Ci	Φ60x1980	4	2
8	Upper door cross tube(left/right)))	Φ60x1800	4	2
9	Upper door cross tube(mid)	(lot o o o o o)o	Φ60x1400	2	2
10	Door frame side cross support tube	() 0 0)	Ф45x1025	4	2
11	Purlin with rings		Ф45х1770	15	2
12	Purlin))	Ф45х1770	20	2
13	Upper door vertical support		Φ60x980	2	1
14	Door frame base rail parts		90x30x1240	4	1
15	Side base rail parts		90x30x1824	8	1
16	Side base rail parts		90x30x1924	2	1
17	Upper door vertical support connector		Φ60/4x60x150	2	1
18	Door sliding cable support hook		3x25	2	1

1


Parts#	Descriptions	Diagram	Dimensions (in mm)	Q'TY	Box
19	Cover conduit		Ф32x1860	2	3
20	Cover conduit		Ф32x1860	8	3
21	Zipper tool(open/close)	□	Φ16x1800	1	3
22	Fixer (at end)	$\bigcirc \bigcirc \bigcirc$	Φ60	22	1
23	Door sliding cable (S:18pcs)	ⅆ <u>┉</u> ᠿ <mark>∍ᠵᠵᠵᠵᠵ<i>ᡪᡪ</i>ᡷᡪᠶᡪᢋᢋᠶᢋᢋᠵᠵᠵᠵᡄ</mark> ᠿᠬ᠋ᢩᡎ	Φ6x5000	2	1
24	Roof bracing cable kit		Φ6x4300	20	1
25	Side wall bracing cable		Φ6x3020	20	1
26	Single-way clamp	0 0	Φ60	16	1
27	Anchor		M16x450	24	1
28	Screw kits	(Jmm)) ()	M8x80	118	1
29	Screw kits for door frame		M8x80	8	1
30	Screw kits for base rail	(jmm)) ()	M8x120	8	1
31	Screws for door base		M8x120	4	1
32	Screw kits and nut for ratchet		M8x15	20	1
33	Ratchet tie-down		3x30x75	10	1
34	Door bracing cable kit		Φ6x5900	4	1
35	Top roof wind bracing strap	Sharen a		3	1
36	Base for #35	<u>_ 0 .</u>	8x60x150	6	1
37	Door Wedge anchor (#36)		M12x120	12	1
38	Strap band(for ratchet)		25x700	10	1
39	Cover locker-up ratchet		T-2	52	1

Parts#	Descriptions	Diagram	Dimensions (in mm)	Q'TY	BOX
40	Ball Type Bungee		Φ5x380	80	1
41	Main Cover			1	3
42	door cover			2	3
43	upper gable cover	20000000000000000000000000000000000000		2	3
44	Wrench	S===E	#13-16	2	1

※リストのBOXナンバーは実際と異なる場合があります。




SH-RO253015 Main Dimension(mm)



※サイズは約です。必ず現物で合わせてください。

Base drawing




※サイズは約です。必ず現物で合わせてください。


6


Frame Assembly Steps

Step 1: Measure the ground according to above drawing, place and connect the base rail parts#14、#15、
#16, fix to ground with#27, install the ratchet on.(put the anchors in concrete before installation, install the shelter after the concrete concreted)




Step 2: Install the end rafter with#1,#2, and#3, #4, #5, crane/lift it into base feet. (To avoid accident, It is very important to hold the first row of rafter with support (wood, rope or similar stuffs), make sure that it won't fall down.)






Step 3 : Install the second row of rafter with #1,#2, and #4, #5, crane/lift it into base feet, then connect to the first row with#11,#12, and brace with #24,#25.


Step 4: The same way to install other rows of rafters.






Step 5: Install the door frames as shown below. Finally to fasten all screws and parts again.

Tips: The tools below may needed while installing the shelter.




Cover Installation


TIPS : Slide the roof cover over assembled frame from one side




insert the conduit to pocket on side:


#38





Step 2 : Attach the cover (#35/#36) to the frame as following :





Note:#38for main roof cover tensioning.

#39 for front and end covers tensioning.

Your assembled shelter will be similar to the illustration as below :


Illustration for Ratchet







(in order to protect the shelter from heavy wind, please install the wind bracing straps at points 300 mm measuring from the ends, and others to be installed in the middle averagely.) (photos are for reference only, the real quantity is according to packing list.)



12