FABRIC BUILDING INSTRUCTIONS

MODEL: SH-RO64

L6.1 x W4 x H 3.55



PICTURE MAY NOT REFLECT THE EXACT MODEL

TO OUR NEW AND VALUED CUSTOMER

Thank you for purchasing your new Instant Shelter. We know you will have as much pleasure owning your new shelter as we had in making it for you. Our shelters have been designed for rapid assembly and minimal maintenance. We have rigorous quality control at every step of the shelters manufacturing process to insure you the best unit money can buy. Our parts are triple checked prior to packaging to insure you will have everything you need before you start. In the unlikely event that a part is damaged or missing, you should immediately contact your place of purchase for a speedy replacement.

About Safety



Working with or under heavy parts included with this shelter can cause serious head injury.

WEAR GLOVES

You will be working with metal parts which may have SHARP edges

CHECK WITH YOUR LOCAL AUTHORITIES

Underground POWER CABLES or GAS LINES may result in injury while securing the shelter. It may also result in having to move the building. A cursory check with the local building authorities will help alleviate these concerns.

CLIMBING EQUIPMENT

It is highly recommended that scaffolding, ladders and mechanical lifting equipment conform to all local building codes when erecting the shelter. Safety straps and harnesses should be used at all times. The metal structure of the shelter has not been designed for human weight. Erecting shelter during wind or rain is unsafe and could result in serious injury.

CHECK LOCAL WEATHER CONDITIONS

Check your local weather forecast prior to planning your building day. Wind, snow and/or rain may cause unsafe conditions that could lead to serious injury.

STORING HAZARDOUS MATERIALS

Check all local building codes prior to storing any hazardous material. Shelter may require additional ventilation to meet local codes.

SEVERE WEATHER CONDITIONS

Working in and around the portable shelter during severe weather is not recommended. Serious injury could result. In the event that extraordinarily severe wind, snow or other severe conditions are predicted and if time permits, it is recommended that the shelter cover be removed.

PREVENT ENTRAPMENT

Check Shelter for co workers before locking up. Always provide for escape in case of emergency.

SHELTER RELOCATION

Should the shelter require relocation or disassembly for any reason, it is strongly recommended that the structure and its cover are thoroughly inspected prior to rebuilding.

PERIODIC SHELTER INSPECTION

As with all structures, periodic inspection of the cover and all structural-components is highly recommended. Tightening the cover and the structure will prolong the life of your investment.

PLEASE BE Safety conscious!

Common Sense is the knack of seeing things as they are, and doing things as they ought to be done.

THANK YOU FOR CHOOSING OUR SHELTER

UNPACKING & IDENTIFYING PARTS

Prior to assembling your New Portable Shelter, unpack all crates and complete an inventory of all parts according to the following list and diagrams

PARTS LIST FOR SH-RO64

Parts#	Descriptions	Diagram	Dimensions (in mm)	Q'TY
1	Roof arched rafter	<u>19</u>	Ф45х2100	3
2	Roof arched rafter		Ф45х2100	2
3	Roof arched rafter	0250	Ф45х2100	3
4	Roof arched rafter(lower end)	2/20	Ф45х2100	2
5	Side upper curved rafter	000000000000000000000000000000000000000	Ф45х1240	10
6	Side vertical rafter(leg)	(Ф45х1500	10
7	Door frame vertical tube(lower)	O •)	Ф45х1500	4
8	Door frame vertical tube(upper)		Ф45х1475	4
9	Upper door cross tube	•	Ф45х1505	2
10	Upper d oor cross tube	00	Ф45х1505	2
10-1	Door framesidecross support tube	() 0 0	Ф45х380	4
11	Purlin with rings		Ф38х1472	12
12	Purlin	<u>)</u>	Ф38х1472	8
13	Upper door vertical support		Ф45х885	2
14	Door frame base rail		25x70x450	4
15	Side base rail		25x70x1514	6
16	Side base rail		25x70x1600	2
17	Upper door vertical support connector		Ф45	2
18	Door sliding cable support hook		3x25	2

PARTS LIST FOR SH-RO64


Parts#	Descriptions	Diagram	Dimensions (in mm)	Q'TY
19	Cover conduit		Ф28х1530	2
20	Cover conduit		Ф28х1530	6
21	Zipper tool(open/close)	□	Ф16х1000	1
22	Fixer		Ф45	15
23	Door sliding cable (S:18pcs)	₫ <u>~</u> @ <u>>>>>> </u>	Ф6х3000	2
24	Roof bracing cable kit		Ф6х2400	16
25	Side wall bracing cable		Ф6х2690	16
26	Singleway clamp	0 0)	Ф45	16
27	Anchor	©0	M16x350	20
28	Screw kits		M8x75	106
29	Screw kits for door frame	(J.1111111) (i)	M8x75	8
30	Screws for base rail		M8x100	6
31	Screws for door base		M8x100	4
32	Screw kits for ratchet		M8x15	16
33	Ratchet tie-down		3x30x75	8
34	Door wind bracing cabl e kit		Ф 6х3720	4
35	Roof wind bracing cable kits	Share of the state		4
36	Base for #35	<u></u>	8x60x150	8
37	DoorWedgeanchor (#36)		M12x120	16
38	Strap band (for ratchet)		25x700	8
39	Cover locker-upratchet		T-2	32

PARTS LIST FOR SH-RO64


Parts#	Descriptions	Diagram	Dimensions (in mm)	Q'TY
40	Ball Type Bungee		Ф 5х330	60
41	Main Cover			1
42	Door cover			2
43	Gable cover	800000		2
44	Wrench	5===€	#13-16	2

PARTS LIST FOR SH-RO64

L6.1 x W4x H3.55m SH-RO64




SH-RO64 Main Dimension(mm)



※サイズは約です。必ず現物で合わせてください。

3000 4000


Base drawing




※サイズは約です。必ず現物で合わせてください。

Frame Assembly Steps


Step 1: Place and connect the base #15, #16, #17, fix to ground with #27 and fasten.




Step 2: Install the end rafters #2,#4 and #5,#6 (To avoid accident, It is very important to hold the first row of rafter with support (wood, rope or similar stuffs), make sure that it won't fall down.)




Step 3:Install the second row of rafters #1, #3 and #5, #6, put into feet and connect with end rafters with #11, #12, then brace with #24,#25.




Step 4: The same way to install other rows of rafters.



Step5: Install the door frames as illustrated below, then fasten all the screws and parts.




Tips: The tools below may needed while installing the shelter.





Roof Cover Assembly

TIPS: Slide the roof cover over assembled frame from one side




insert the conduit to pocket on side:






Step 2: Attach the cover (#35/#36) to the frame as following:



Note:#39 for main roof cover tensioning. #40 for front and end covers tensioning.

Your assembled shelter will be similar to the illustration as below:

Illustration for Ratchet







(in order to protect the shelter from heavy wind, please install the wind bracing straps at points 300 mm measuring from the ends, and others to be installed in the middle averagely.) (photos are for reference only, the real quantity is according to packing list.)

